

INSTRUCTIONS FOR THE APPLICATION OF IDEAL HARD

1. The floor must be dry.
The floor temperature must be between 5-30°C.
Protect iron, aluminium and glass.
2. Spread IDEAL HARD with a watering can on the floor, using 200g/m².
3. Massage the floor for about 30-35 minutes in several passes (minimum 5) with a single brush with soft bristles or red disc.

ATTENTION!!!

Where the floor dries, spray more product.

Do not let dry the product on the joints.

4. After 35-40 minutes, spray some water on the floor.
5. Massage with a floor machine for another 10 minutes (minimum 2 coats).
6. Rinse with clean water at least 2 times, taking care not to leave residue.

NB: At this stage, take great care to avoid creating shiny patches caused by the residual product.